






































| Originale | Sostituto |
|--|--|
|  Standby |  Power |
|  Source |  AV |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Fav |  Pre Ch |
|  Recall |  Back |
|  P.Mode |  Format |
|  S.Mode |  Shift + Dual |
|  Sleep |  Sleep |

| Originale | Sostituto |
|--|---|
|  Tv/Radio |  TV/R |
|  Display |  Info |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  Ok |  Ok |
|  Menu |  Menu |
|  Exit |  Exit |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Mute |  Mute |
|  Epg |  Guide |
|  Media |  Media |
|  Ch+ |  Ch + |
|  Ch- |  Ch - |
|  Rec |  Rec |





| Originale | | Sostituto | | Originale | | Sostituto | |
|-----------|----------------|-----------|---------|-----------|--------|-----------|--------|
| | T.Shift | | Options | | Green | | Green |
| | I/II Audio | | Dual | | Yellow | | Yellow |
| | Size/Aspect | | 3D | | Blue | | Blue |
| | Text | | Text | | | | |
| | Reveal | | D. Menu | | | | |
| | Subpage | | Smart | | | | |
| | Hold | | Eject | | | | |
| | Subtitle | | Subt | | | | |
| | Index/Rec List | | List | | | | |
| | Play | | Play | | | | |
| | Pause | | Pause | | | | |
| | Stop | | Stop | | | | |
| | << | | << | | | | |
| | >> | | >> | | | | |
| | I<< | | I<< | | | | |
| | >>I | | >>I | | | | |
| | Red | | Red | | | | |

