




















Originale	Sostituto
	Mute / Dimmer
	Picture / Format
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	AV / Input / RDS
	0
	Back / Return
	D.Menu / Top
	Fav / Marker / PC

Originale	Sostituto
	TV/Radio /
	Menu / Home
	Text / Goto
	Up
	Left
	OK
	Right
	Down
	Vol+
	CH+ / Page+
	Vol-
	CH- / Page-
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Info / Angle





Originale	Sostituto	Originale	Sostituto
	[?] SMART Smart / List		
	[+] SIZE ZOOM Zoom / Size		
	[◆] MEDIA DISPLAY Display / Media		
	[≡x] SURROUND Eject / Surround		
	[:≡] GUIDE EPG Guide / EPG / -/-		
	[] EQ Subtitle / EQ		
	♪ TITLE SOUND Sound / Title		

