



Originale	Sostituto
 Power	 Power
 Wide	 3D
 TV	 TV/R
 Video	 AV
 RGB	 Media
 Teletext	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 CH+	 Ch +

Originale	Sostituto
 CH-	 Ch -
 CH Return	 Pre Ch
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Menu	 Menu
 Dual/Stereo	 Dual
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Subpage	 Subt





Originale		Sostituto		Originale		Sostituto	
	Reveal		Options				
	Size		Format				
	Hold		Smart				
	Index		Guide				
	Mode		Back				
	Cancel		Exit				
	Store		Rec				
	Display		Info				
	Picture Memory		List				
	Picture Mode		D. Menu				
	Off-Timer		Sleep				

