







































































Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PIP/Audio	 3D
 [<>]	 Format
 ?	 Smart
 Mute	 Mute
 Z/Disc Menu	 Menu
 i/OSD	 Info

Originale	Sostituto
 TXT	 Text
 TV-G	 Guide
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 P+	 Ch +
 P-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Red/Image/I>	 Red
 Green/Timer	 Green
 Yellow/@	 Yellow
 Blue/Sound	 Blue
 Play	 Play
 Pause	 Pause









































































	Originale	Sostituto
	Stop	Stop
	<<	<<
	>>	>>
	I<	I<<
	>I	>>I

	Originale	Sostituto













Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PIP/Audio	 3D
 [<>]	 Format
 ?	 Smart
 i/OSD	 Info
 TXT	 Text
 TV-G	 Guide

Originale	Sostituto
 Z/Disc Menu	 Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 P+	 Ch +
 P-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Red/Image/I>	 Red
 Green/Timer	 Green
 Yellow/@	 Yellow
 Blue/Sound	 Blue
 Play	 Play
 Pause	 Pause
 Stop	 Stop

























































	Originale	Sostituto		Sostituto
	<<		<<	<<
	>>		>>	>>
	>		>>	>>
	<		<<	<<

Originale	Sostituto





Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PIP/Audio	 3D
 [ <> ]	 Format
 ?	 Smart
 Mute	 Mute
 i/OSD	 Info
 TXT	 Text

Originale	Sostituto
 Z/Disc Menu	 Menu
 TV-G	 Guide
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 P+	 Ch +
 P-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Red/Image/ >	 Red
 Green/Timer	 Green
 Yellow/@	 Yellow
 Blue/Sound	 Blue
 Play	 Play
 Pause	 Pause









































































	Originale	Sostituto	Originale	Sostituto
	Stop			
	<<			
	>>			
	I<			
	>I			













Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PIP/Audio	 3D
 [<>]	 Format
 ?	 Smart
 i/OSD	 Info
 TXT	 Text
 TV-G	 Guide

Originale	Sostituto
 Z/Disc Menu	 Menu
 P+	 Ch +
 P-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Red/Image/I>	 Red
 Green/Timer	 Green
 Yellow/@	 Yellow
 Blue/Sound	 Blue
 Play	 Play
 Pause	 Pause
 Stop	 Stop





	Originale	Sostituto		Sostituto
	<<		<<	
	>>		>>	
	I<		I<<	
	>I		>>I	

	Originale	Sostituto

