







































































| Originale | | Sostituto | | Originale | | Sostituto | |
|---|----------|---|-----------------------|---|--------|---|-------------------|
|  | Standby |  | Power |  | Right |  | Right |
|  | Info |  | Info / Angle |  | Vol+ |  | Vol+ |
|  | Subtitle |  | Subtitle / EQ |  | Record |  | Rec / Rec Mode |
|  | Mute |  | Mute / Dimmer |  | Down |  | Down |
|  | I<< |  | I<< / Preset- |  | CH- |  | CH- / Page- |
|  | Play |  | Play / Slow |  | Stop |  | Stop / Hold |
|  | << |  | << / Tune- |  | 1 |  | 1 |
|  | >>I |  | >>I / Preset+ |  | 2 |  | 2 |
|  | Pause |  | Pause / Step / Freeze |  | 3 |  | 3 |
|  | >> |  | >> / Tune+ |  | EPG |  | Guide / EPG / -/- |
|  | Menu |  | Menu / Home |  | 4 |  | 4 |
|  | Up |  | Up |  | 5 |  | 5 |
|  | CH+ |  | CH+ / Page+ |  | 6 |  | 6 |
|  | Exit |  | Exit / Cancel / Clear |  | Back |  | Back / Return |
|  | Left |  | Left |  | 7 |  | 7 |
|  | Vol- |  | Vol- |  | 8 |  | 8 |
|  | OK |  | OK |  | 9 |  | 9 |





| Originale | | Sostituto | |
|-----------|----------|-----------|-----------------------------|
| | 0 | | 0 |
| | Media | | Display / Media |
| | USB | + | Shift + 8 |
| | Tv/Radio | | TV/Radio / |
| | Audio | | Audio / Lang I/II |
| | TTX | | Text / Goto |
| | Timer | | Sleep / Timer |
| | FAV | | Fav / Marker / PC |
| | Res | | D.Menu / Top |
| | Red | | Red / Netflix / Search |
| | Green | | Green / APP / Repeat |
| | Yellow | | Yellow / YouTube / Repeat |
| | Blue | | Blue / Prime Video / Random |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | | Sostituto | |
|-----------|--|-----------|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

