







































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 PR +	 Up
 Mute	 Mute	 PR -	 Ch -
 1	 1	 PR -	 Down
 2	 2	 Vol +	 Vol +
 3	 3	 Vol +	 Right
 4	 4	 Vol -	 Vol -
 5	 5	 Vol -	 Left
 6	 6	 OK	 Ok
 7	 7	 SWAP	 Back
 8	 8	 16:9	 Format
 9	 9	 White / i	 Info
 0	 0	 Red	 Red
 --	 GUIDE	 Green	 Green
 AV / TV	 TV/R	 Yellow	 Yellow
 Menu	 Menu	 Blue	 Blue
 TXT	 Text	 Stop	 Stop
 PR +	 Ch +	 Reveal	 Smart

Originale	Sostituto	Originale	Sostituto
 PR +	 Up	 TV	 AUX
 PR -	 Ch -	 DVD	 SAT
 PR -	 Down	 SLEEP	 REC MODE
 Vol +	 Vol +	 DUAL	 SUBT
 Vol +	 Right	 SEARCH	 PICTURE
 Vol -	 Vol -	 E-MANUAL	 REPEAT
 Vol -	 Left	 D.MENU	 TEXT
 OK	 Ok	 ZOOM	 TIMER
 SWAP	 Back	 TOP MENU	 DISPLAY INFO
 16:9	 Format	 MENU	 OK
 White / i	 Info	 CLEAR	 RETURN BACK
 Red	 Red	 EXIT	 BACK
 Green	 Green	 HOME	 SMART
 Yellow	 Yellow	 + VOL	 + CH
 Blue	 Blue	 - VOL	 - CH
 Stop	 Stop	 APP	 MEDIA
 Reveal	 Smart	 1	 2
		 3	 4
		 5	 6
		 7	 8
		 8	 9
		 9	 0
		 GUIDE	 0
		 FAV	 PRE-CH
		 A	 B
		 C	 D
		 D	 D
		 STOP	 STOP
		 HOME SMART	 HOME SMART



