







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Mute		Mute
	Netflix		Media		[i]		Info
	TV		TV/R		P+		Ch +
	1		1		P-		Ch -
	2		2		*		Menu
	3		3		Home		Smart
	4		4		Guide		Guide
	5		5		≡		Options
	6		6		Back		Back
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	Eco		3D		OK		Ok
	Source		AV		Exit		Exit
	Vol+		Vol +		Zoom+		Shift + Ch +
	Vol-		Vol -		Zoom-		Shift + Ch -





Originale	Sostituto
List	List
Sleep	Sleep
PRE-CH	Pre Ch
FAV	Shift + Pre Ch
Rec	Rec
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Lang	Dual
Subtitle	Subt
Text	Text
I<	I<<
Stop	Stop
Play	Play
>I	>>I
<<	<<

Originale	Sostituto
Pause	Pause
>>	>>

