







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Right		Right
	[+]		3D		Left		Left
	[i+]/[?]		Info		OK		Ok
	Digital		Media		Menu		Menu
	Analog		Smart		1		1
	[> <]		Format		2		2
	Audio		Dual		3		3
	Red		Red		4		4
	Green		Green		5		5
	Yellow		Yellow		6		6
	Blue		Blue		7		7
	Guide		Guide		8		8
	Input		AV		9		9
	Return		Back		0		0
	Tools		Options		[≡]		Text
	Up		Up		♥		Shift + Pre Ch
	Down		Down		Vol+		Vol +



