



Originale	Sostituto	Originale	Sostituto
Standby	Power	Pause	Pause / Step / Freeze
1	1	Vol -	Vol-
2	2	Up	Up
3	3	Left	Left
4	4	OK	OK
5	5	Right	Right
6	6	Down	Down
7	7	Exit	Exit / Cancel / Clear
8	8	Menu	Menu / Home
9	9	Red / SUB-T	Subtitle / EQ
TV / STB	AV / Input / RDS	Red / SUB-T	Red / Netflix / Search
0	0	Green	Green / APP / Repeat
TV / Radio	TV/Radio /	Yellow / Timer	Yellow / YouTube / Repeat
CH +	CH + / Page+	Blue / Info	Blue / Prime Video / Random
Mute	Mute / Dimmer	Blue / Info	Info / Angle
Vol +	Vol+	P.STD	Picture / Format
CH -	CH - / Page-	P.Size	Zoom / Size

Originale	Sostituto	Originale	Sostituto
Standby	Power	Pause	Pause / Step / Freeze
1	1	Vol -	Vol-
2	2	Up	Up
3	3	Left	Left
4	4	OK	OK
5	5	Right	Right
6	6	Down	Down
7	7	Exit	Exit / Cancel / Clear
8	8	Menu	Menu / Home
9	9	Red / SUB-T	Subtitle / EQ
TV / STB	AV / Input / RDS	Red / SUB-T	Red / Netflix / Search
0	0	Green	Green / APP / Repeat
TV / Radio	TV/Radio /	Yellow / Timer	Yellow / YouTube / Repeat
CH +	CH + / Page+	Blue / Info	Blue / Prime Video / Random
Mute	Mute / Dimmer	Blue / Info	Info / Angle
Vol +	Vol+	P.STD	Picture / Format
CH -	CH - / Page-	P.Size	Zoom / Size



