





































Originale	Sostituto
 Standby	 Power
 Info	 Info
 Subtitle	 Subt
 Mute	 Mute
 I<<	 I<<
 >>I	 >>I
 Play	 Play
 Pause	 Pause
 <<	 <<
 >>	 >>
 Menu	 Menu
 Exit	 Exit
 Up / CH +	 Up
 Up / CH +	 Ch +
 Down / CH -	 Down
 Down / CH -	 Ch -
 Right / Vol +	 Right

Originale	Sostituto
 Right / Vol +	 Vol +
 Left / Vol -	 Left
 Left / Vol -	 Vol -
 OK	 Ok
 Record	 Rec
 Stop	 Stop
 Res	 Format
 Goto	 Guide
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9



