




Originale		Sostituto		Originale		Sostituto	
	Power		Power		Ch.List		List
	Source		AV		P +		Ch +
	1		1		P -		Ch -
	2		2		Media.P		Media
	3		3		Menu		Menu
	4		4		Guide		Guide
	5		5		Tools		Options
	6		6		Info		Info
	7		7		Up		Up
	8		8		Right		Right
	9		9		Down		Down
	0		0		Left		Left
	TTX/MIX		Text		Enter		Ok
	PRE-CH		Pre Ch		Return		Back
	Vol+		Vol +		Exit		Exit
	Vol-		Vol -		Red		Red
	Mute		Mute		Green		Green





Originale	Sostituto
 Yellow	 Yellow
 Blue	 Blue
 P.Mode	 Shift + Format
 Dual I/II	 Dual
 3D	 3D
 AD	 Shift + Subt
 P.Size	 Format
 Subt.	 Subt
 <<	 <<
 Pause	 Pause
 >>	 >>
 Rec	 Rec
 Play	 Play
 Stop	 Stop

Originale	Sostituto

