



Originale	Sostituto
Power TV	Power
Power STB	+ Shift + Power
Source	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
TTX/MIX	Text
PRE-CH	Pre Ch
Vol+	Vol +
Vol-	Vol -

Originale	Sostituto
Mute	Mute
CH.List	List
P+	Ch +
P-	Ch -
Menu	Menu
Smart Hub	Smart
Guide	Guide
Tools	Options
Info	Info
Back/Return	Back
Exit	Exit
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Red	Red





	Originale	Sostituto	Originale	Sostituto
	Green	Green		
	Yellow	Yellow		
	Blue	Blue		
	D	SOUND DUAL		
	STATUS	SEARCH TV/R		
	MORE	ECO 3D		
	E-Manual	E-MANUAL D. Menu		
	Recommend	PICTURE FORMAT		
	AD/Subt	AD Subt		
	<<<	<<<		
	I<<<	I<<<		
	Pause	Pause		
	>>>	>>>		
	>>I	>>I		
	Rec	REC MODE		
	Play	PLAY MODE		
	Stop	Stop		

