




Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 [≡⇅] / Sleep	 Shift + Power
 [≡●] / Pre-CH	 Pre Ch
 Mute	 Mute
 Vol +	 Vol +
 Vol -	 Vol -
 P +	 Ch +

Originale	Sostituto
 P -	 Ch -
 [≡□] / Source	 AV
 [≡i] / Menu	 Menu
 TTX / MIX	 Text
 [≡?] / Info	 Info
 Exit / TV	 Exit
 Up	 Up
 Left	 Left
 Enter	 Ok
 Right	 Right
 Down	 Down
 Red / P.Size	 Red
 Green / Still	 Green
 Yellow / Dual I-II	 Yellow
 Yellow / Dual I-II	 Dual
 Blue / SRS	 Blue
 PIP	 Smart





Originale		Sostituto		Originale		Sostituto	
	PIP Source		Media				
	PIP P +		Shift + Ch +				
	PIP P -		Shift + Ch -				
	PIP Size		Shift + Smart				
	→ □ ← / P.Mode		Format				
	[≡X] / S.Mode		Shift + Dual				
	E.Saving		3D				

