








Originale	Sostituto	Originale	Sostituto
 Mute	 Mute	 5	 5
 Program	 Sleep	 6	 6
 Shuffle	 TV/R	 7	 7
 Open / Close	 Exit	 8	 8
 Time	 AV	 9	 9
 Audio	 Shift + Dual	 0	 0
 Zoom	 Eject	 10+	 Guide
 N/P	 3D	 PBC	 Media
 Repeat	 Text	 Slow	 Shift + Play
 A-B	 Shift + Text	 Display	 Info
 Goto	 Smart	 Clear	 Shift + Exit
 Language	 Dual	 I<< Prev	 I<<
 Subtitle	 Subt	 >>I Next	 >>I
 1	 1	 << FR	 <<
 2	 2	 >> FF	 >>
 3	 3	 Setup	 Options
 4	 4	 Angle	 Format

Originale	Sostituto	Originale	Sostituto
 5	 5	 5	 5
 6	 6	 6	 6
 7	 7	 7	 7
 8	 8	 8	 8
 9	 9	 9	 9
 0	 0	 0	 0
 10+	 Guide	 10+	 Guide
 PBC	 Media	 PBC	 Media
 Slow	 Shift + Play	 Slow	 Shift + Play
 Display	 Info	 Display	 Info
 Clear	 Shift + Exit	 Clear	 Shift + Exit
 I<< Prev	 I<<	 I<< Prev	 I<<
 >>I Next	 >>I	 >>I Next	 >>I
 << FR	 <<	 << FR	 <<
 >> FF	 >>	 >> FF	 >>
 Setup	 Options	 Setup	 Options
 Angle	 Format	 Angle	 Format





Originale	Sostituto
Up	Up
Left	Left
Enter	Ok
Right	Right
Down	Down
Menu	Menu
Title	List
Resume	Yellow
Stop	Stop
Step	Pause
Play / Pause	Play

Originale	Sostituto

