










| Originale   | Sostituto   |
|---|---|
|  Power   |  Power   |
|  Setup   |  Options |
|  DTV     |  D. Menu |
|  HDMI/AV |  AV      |
|  1       |  1       |
|  Disk    |  List    |
|  2       |  2       |
|  3       |  3       |
|  4       |  4       |
|  5       |  5       |
|  6      |  6      |
|  7     |  7     |
|  8     |  8     |
|  9     |  9     |
|  0     |  0     |
|  TTX   |  Text  |
|  EPG   |  Guide |

| Originale  | Sostituto  |
|--|--|
|  Movie    |  Red            |
|  Music    |  Green          |
|  Photo    |  Yellow         |
|  Vol+     |  Vol +          |
|  Vol-     |  Vol -          |
|  Up       |  Up             |
|  Down     |  Down           |
|  Right    |  Right          |
|  Left     |  Left           |
|  Enter    |  Ok             |
|  Exit    |  Exit          |
|  Home   |  Smart        |
|  Edit   |  TV/R         |
|  Copy   |  3D           |
|  Repeat |  Shift + Text |
|  Rec    |  Rec          |
|  Play   |  Play         |





|  | Originale | Sostituto  |
|--|-----------|--|
|  PLAY/PAUSE | Pause     |  Pause                                      |
|  STOP       | Stop      |  Stop                                       |
|  REV        | <</Rev    |  <<   |
|  F.F.       | >>/FF     |  >>   |
|  PG.DN      | >>I       |  >>I  |
|  PG.UP      | I<<       |  I<<  |
|  PG.UP      | PG Up     |  +<br>CH<br>+                               |
|  PG.DN      | Pg Dn     |  -<br>CH<br>-                               |
|  AUDIO      | Audio     |  SOUND<br>DUAL                              |
|  SUB-T      | Sub-T     |  AD<br>SUBT                                 |
|  FAV        | FAV       |  FAV<br>PRE-CH                              |
|  INFO      | Info      |  DISPLAY<br>INFO                           |
|  MUTE     | Mute      |  MUTE                                     |
|  DVD      | DVD       |  D<br>Blue                                |
|  TIMER    | Timer     |  SHIFT +<br>TIMER<br>AV<br>Shift +<br>AV |
|  T/R      | T/R       |  PICTURE<br>FORMAT<br>Format              |

| Originale | Sostituto |
|-----------|-----------|
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |

