







Originale	Sostituto
 Power	 Power
 Display	 Info
 Mute	 Mute
 TV	 TV/R
 AV	 AV
 Scart	 Smart
 PC	 Media
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Originale	Sostituto
 0	 0
 Recall	 Pre Ch
 Enter	 Guide
 Menu	 Menu
 TTX/MIX	 Text
 Wide	 3D
 MPX	 Options
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Red	 Red





Originale	Sostituto	Originale	Sostituto
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Subtitle	 Subt		
 Index	 List		
 Subpage	 D. Menu		
 Reveal	 Dual		
 Size	 Format		
 Hold	 Eject		

Originale	Sostituto

