






































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Exit/Back		Exit
	Mute		Mute		Up		Up
	1		1		Left		Left
	2		2		OK		Ok
	3		3		Right		Right
	4		4		Down		Down
	5		5		P+		Ch +
	6		6		P-		Ch -
	7		7		Vol+		Vol +
	8		8		Vol-		Vol -
	9		9		[<<]>		Format
	0		0		→ █ ←		TV/R
	Recall		Pre Ch		[i+] / [≡i]		Info
	Source		AV		Text / [≡] / [≡] [ ]		Text
	Menu/DVD		Menu		▄▄▄▶ / ▾		Pause
	Guide		Guide		▶ / I/II		Play
	[ ■ ] [▄▄▄]		3D		▶ / I/II		Dual









































































Originale	Sostituto	Originale	Sostituto
 <<< / [≡⏪]	 <<<		
 << / [≡⏩]	 OPT Options		
 >>> / Subtitle	 AD SUBT Subt		
 >>> / Subtitle	 >>>		
 ▲	 HOME SMART Smart		
 ■ / [≡□]	 Stop		
 ■◀ / [≡⇆]	 ZOOM Eject		
 ■◀ / [≡⇆]	 I<<<		
 ▶▶▶ / [⊖] [≡X]	 >>>I		
 ▶▶▶ / [⊖] [≡X]	 RETURN BACK Back		
 Red	 A Red		
 Green	 B Green		
 Yellow	 C Yellow		
 Blue	 D Blue		

Originale	Sostituto	Originale	Sostituto





















































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Right		Right
	Mute		Mute		Down		Down
	1		1		Vol+		Vol +
	2		2		Vol-		Vol -
	3		3		▶ / [v]		Pause
	4		4		▶ / I/II		Play
	5		5		▶ / I/II		Dual
	6		6		◀◀ / [≡●]		<<
	7		7		◀◀ / [≡●]		TV/R
	8		8		▶▶ / Subtitle		>>
	9		9		▶▶ / Subtitle		Subt
	0		0		▲		Smart
	_ Menu/DVD		Menu		■ / [≡□]		Stop
	- Exit/Back		Exit		◀◀◀ / [≡⇅]		Eject
	- Up		Up		◀◀◀ / [≡⇅]		I<<
	Left		Left		▶▶▶ / [⊙][≡X]		>>I
	OK		Ok		▶▶▶ / [⊙][≡X]		Back







Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Mute	 Mute
 1	 1	 2	 2
 3	 3	 4	 4
 5	 5	 6	 6
 7	 7	 8	 8
 9	 9	 0	 0
 Source	 AV	 P+	 Ch +
 P-	 Ch -	 Vol-	 Vol -
 Vol+	 Vol +		

Originale	Sostituto	Originale	Sostituto
 Pause	 Pause	 Play	 Play
 Dual	 Dual	 <<<	 <<<
 TV/R	 TV/R	 Subtitle	 >>>
 Smart	 Subt	 Stop	 Smart
 Eject	 Eject	 Back	 Back
 >>>	 >>>		

