



Originale	Sostituto
	Power
	Source
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	TTX/MIX
	PRE-CH
	Vol+
	Vol-
	Mute

Originale	Sostituto
	CH List
	P+ / Page+
	P- / Page-
	Smart Hub
	Menu
	Guide
	Tools
	Info
	Up
	Left
	Enter
	Right
	Down
	Return
	Exit
	Red
	Green





Originale		Sostituto		Originale		Sostituto	
	Yellow		Yellow				
	Blue		Blue				
	Rec		Rec				
	3D		3D				
	AD/Subt.		Subt				
	Stop		Stop				
	<</ <<		<<				
	<</ <<		<<				
	Play		Play				
	Pause		Pause				
	>>/>>		>>				
	>>/>>		>>				

