



| Originale | | Sostituto | | Originale | | Sostituto | |
|-----------|-----------|-----------|-------------|-----------|--------|-----------|-----------------------------|
| | Power | | Power | | -- | | Guide / EPG / -/-- |
| | Up / P+ | | Up | | 0 | | 0 |
| | Up / P+ | | CH+ / Page+ | | P < P | | Fav / Marker / PC |
| | Menu | | Menu / Home | | PP | | Back / Return |
| | Left | | Left | | Vol+ | | Vol+ |
| | Right | | Right | | I-II | | Audio / Lang I/II |
| | Down / P- | | Down | | Mute | | Mute / Dimmer |
| | Down / P- | | CH- / Page- | | Vol- | | Vol- |
| | 1 | | 1 | | Info | | Info / Angle |
| | 2 | | 2 | | Red | | Red / Netflix / Search |
| | 3 | | 3 | | Green | | Green / APP / Repeat |
| | 4 | | 4 | | Yellow | | Yellow / YouTube / Repeat |
| | 5 | | 5 | | Blue | | Blue / Prime Video / Random |
| | 6 | | 6 | | [TV] | | Shift + 1 |
| | 7 | | 7 | | [TV] | | TV/Radio / |
| | 8 | | 8 | | [AV] | | AV / Input / RDS |
| | 9 | | 9 | | [≡] | | Text / Goto |









































































| Originale | Sostituto |
|-----------|-------------|
| Power | Power |
| Up / P+ | Up |
| Up / P+ | CH+ / Page+ |
| Menu | Menu / Home |
| Left | Left |
| Select | OK |
| Right | Right |
| Down / P- | CH- / Page- |
| Down / P- | Down |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |

| Originale | Sostituto |
|------------|-----------------------------|
| 9 | 9 |
| +10 | Guide / EPG / -/- |
| 0 | 0 |
| Repeat | Green / APP / Repeat |
| Search | Red / Netflix / Search |
| A→B | Yellow / YouTube / Repeat |
| Display | Display / Media |
| Audio | Audio / Lang I/II |
| Subtitle | Subtitle / EQ |
| Zoom | Zoom / Size |
| Prog | TV/Radio / |
| C | Blue / Prime Video / Random |
| Angle | Info / Angle |
| Return | Back / Return |
| Time | Sleep / Timer |
| << / Tune- | << / Tune- |
| >> / Tune+ | >> / Tune+ |





| Originale | Sostituto | Originale | Sostituto |
|-------------|---|------------|---|
| On/Off |  Power | Menu Right |  Right |
| Mute |  Mute / Dimmer | Menu Down |  Down |
| Txt Stop |  Stop / Hold | Back |  Back / Return |
| Tone+ |  >> / Tune+ | Volume+ |  Vol+ |
| Lang |  Sound / Title | Chan.Up |  CH+ / Page+ |
| Menu audio |  Audio / Lang I/II | Volume- |  Vol- |
| Subt.List |  Subtitle / EQ | Display |  Display / Media |
| Txt Expand |  Zoom / Size | Chan.Down |  CH- / Page- |
| Sleep Timer |  Sleep / Timer | 1 |  1 |
| Return TV |  TV/Radio / | 2 |  2 |
| Menu video |  D.Menu / Top | 3 |  3 |
| Text |  Text / Goto | 4 |  4 |
| Menu |  Menu / Home | 5 |  5 |
| Menu Up |  Up | 6 |  6 |
| Info |  Info / Angle | 7 |  7 |
| Menu Left |  Left | 8 |  8 |
| OK Enter |  OK | 9 |  9 |

| Originale | Sostituto | Originale | Sostituto |
|-------------|---|------------|---|
| On/Off |  Power | Menu Right |  Right |
| Mute |  Mute / Dimmer | Menu Down |  Down |
| Txt Stop |  Stop / Hold | Back |  Back / Return |
| Tone+ |  >> / Tune+ | Volume+ |  Vol+ |
| Lang |  Sound / Title | Chan.Up |  CH+ / Page+ |
| Menu audio |  Audio / Lang I/II | Volume- |  Vol- |
| Subt.List |  Subtitle / EQ | Display |  Display / Media |
| Txt Expand |  Zoom / Size | Chan.Down |  CH- / Page- |
| Sleep Timer |  Sleep / Timer | 1 |  1 |
| Return TV |  TV/Radio / | 2 |  2 |
| Menu video |  D.Menu / Top | 3 |  3 |
| Text |  Text / Goto | 4 |  4 |
| Menu |  Menu / Home | 5 |  5 |
| Menu Up |  Up | 6 |  6 |
| Info |  Info / Angle | 7 |  7 |
| Menu Left |  Left | 8 |  8 |
| OK Enter |  OK | 9 |  9 |



