









































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info
 Recall	 Back
 Menu	 Menu
 EPG	 Guide
 Exit	 Exit

Originale	Sostituto
 FAV	 Pre Ch
 Page+	 Ch +
 Page-	 Ch -
 Up/CH+	 Up
 Down/CH-	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Audio	 Dual
 Pause	 Pause
 TTX	 Text





Originale	Sostituto
 Subtitle	 Subt
 Tv/Radio	 TV/R

Originale	Sostituto

