

























	Originale	Sostituto	Originale	Sostituto
	Power	 Power		
	((·))	 Smart		
	+	 Vol +		
	-	 Vol -		
	>>	 >>		
	<<	 <<		
	Play	 Play		
	Pause	 Pause		
	Up	 Up		
	Down	 Down		
	Menu	 Menu		
	Select	 Ok		
	X	 Exit		
	Recall	 Back		

