







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		5		5
	▶▶		3D		6		6
	←		Back		7		7
	SAT		Smart		8		8
	Mute		Mute		9		9
	TV		TV/R		0		0
	[=]		Text		-/--		Guide
	→ / []		AV		C		Exit
	□ → / [?]		Shift + AV		[=+]		Shift + Stop
	PIP / Split		Options		↑		Up
	PIP to Main		List		Vol+		Vol +
	PIP Swap / Split Swap		Pre Ch		Vol-		Vol -
	Split Hold		Shift + Pause		Prog+		Ch +
	1		1		Prog-		Ch -
	2		2		Red		Red
	3		3		Green		Green
	4		4		Yellow		Yellow



