




Originale	Sostituto
 Power	 Power
 Sleep	 Sleep
 Muting	 Mute
 1 / Disc 1	 1
 2 / Disc 2	 2
 3 / Disc 3	 3
 4 / Disc 4	 4
 5 / Disc 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 ≥10	 Guide
 Disc	 Media
 Program	 +  Shift + Sleep
 Cancel	 Back

Originale	Sostituto
 Repeat	 Text
 Random	 Options
 Tape	 Red
 CD	 Green
 Tuner	 Yellow
 AUX	 Blue
 EQ	 Subt
 3D AI	 3D
 I<</>>	 <<
 I<</>>	 I<<
 >>/>>I	 >>I
 >>/>>I	 >>
 Play Rev / Pause / Down	 Pause
 Play Rev / Pause / Down	 Down
 Play Rev / Pause / Down	 Left
 Stop	 Stop
 Stop	 Exit





Originale		Sostituto	
	Play / Up		Play
	Play / Up		Up
	Play / Up		Right
	Volume -		Vol -
	Volume +		Vol +

Originale		Sostituto	

