


























| Originale  | Sostituto  |
|--|--|
|  Power      |  Power    |
|  Mute       |  Mute     |
|  TV / Video |  TV/R     |
|  V.Size     |  Eject    |
|  PIP        |  Smart    |
|  1          |  1        |
|  2          |  2        |
|  3          |  3        |
|  4          |  4        |
|  5          |  5        |
|  6         |  6       |
|  7        |  7      |
|  8        |  8      |
|  9        |  9      |
|  0        |  0      |
|  Text     |  Text   |
|  Pre Pg   |  Pre Ch |

| Originale  | Sostituto  |
|--|--|
|  Menu / Sel   |  Menu     |
|  Menu / Sel   |  Ok       |
|  Exit         |  Exit     |
|  Up / PG+     |  Up       |
|  Up / PG+     |  Ch +     |
|  Down / PG-   |  Down     |
|  Down / PG-   |  Ch -     |
|  Right / Vol+ |  Right    |
|  Right / Vol+ |  Vol +    |
|  Left / Vol-  |  Left     |
|  Left / Vol- |  Vol -   |
|  MTS        |  Media  |
|  PG Info    |  Info   |
|  Still      |  Pause  |
|  Picture    |  Format |
|  Sound      |  Dual   |
|  Sleep      |  Sleep  |



