







































Originale	Sostituto
 POWER	 Power
 PLAY/PAUSE	 Pause
 INPUT	 AV
 ^	 Up
 ENTER	 Ok
 v	 Down
 <	 Left
 >	 Right
 VOL +	 Vol +
 VOL -	 Vol -
 MUTE	 Mute
 DISPLAY	 Info
 REPEAT	 Text
 SUBTITLE	 Subt
 ZOOM	 Eject
 RESET	 Back
 STOP	 Stop

Originale	Sostituto
 <<	 <<
 PLAY/PAUSE	 Play
 >>	 >>

