



Originale	Sostituto
Power	Power
Open/Close	Eject
On Screen	Info
1	1
Repeat	Text
2	2
Program	Shift + Sleep
3	3
Surround	List
4	4
Sound	Shift + Dual
5	5
Zoom	Shift + Eject
6	6
7	7
8	8
9	9

Originale	Sostituto
0	0
Sleep	Sleep
Aspect	Format
Source	AV
Color Mode	Media
Break	Exit
Play	Play
<<	<<
Pause	Pause
>>	>>
Stop	Stop
>>	>>
Top Menu	D. Menu
Top Menu	Shift + Menu
Menu	Menu
Up	Up



