




















































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Left	 Left
 Open / Close	 Exit	 Enter	 Ok
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 Menu	 Menu
 4	 4	 Audio / RL	 Dual
 5	 5	 OSD	 Info
 6	 6	 Zoom	 Eject
 7	 7	 Subtitle	 Subt
 8	 8	 DVD / USB	 Media
 9	 9	 Play / Pause	 Play
 0	 0	 Stop	 Stop
 Vol-	 Vol -	 Repeat	 Text
 Vol+	 Vol +	 Angle	 Format
 Setup	 Options	 <<	 <<
 Search	 TV/R	 >>	 >>
 Up	 Up	 I<<	 I<<

Originale	Sostituto	Originale	Sostituto
 MUTE	 MUTE	 SHIFT	 SHIFT
 TV	 TV	 DVD	 DVD
 SAT	 SAT	 AUX	 AUX
 PLAY MODE	 PLAY MODE	 REC MODE	 REC MODE
 Play	 Play	 Pause	 Pause
 Stop	 Stop	 >>	 >>
 <<	 <<	 SOUND	 AD
 >>	 >>	 SETTINGS	 OPT
 DISC NAV	 DISC NAV	 DUAL	 SUBT
 LIST	 LIST	 PICTURE	 ECO
 PROG	 PROG	 SLEEP	 TV/R
 SEARCH	 SEARCH	 FORMAT	 3D
 E-MANUAL	 E-MANUAL	 REPEAT	 ZOOM
 D.MENU	 D.MENU	 TEXT	 TIMER
 TOP MENU	 TOP MENU	 MENU	 AV
 DISPLAY	 DISPLAY	 DUAL	 DUAL
 INFO	 INFO	 ZOOM	 ZOOM
 OK	 OK	 AD	 AD
 Left	 Left	 SUBT	 SUBT
 Right	 Right	 APP	 MEDIA
 Up	 Up	 HOME	 SMART
 Down	 Down	 APP	 MEDIA
 Left	 Left	 CH +	 CH +
 Right	 Right	 CH -	 CH -
 Up	 Up	 1	 2
 Down	 Down	 3	 4
 Left	 Left	 5	 6
 Right	 Right	 6	 7
 Up	 Up	 7	 8
 Down	 Down	 8	 9
 Left	 Left	 9	 0
 Right	 Right	 0	 FAV
 Up	 Up	 GUIDE	 PRE-CH
 Down	 Down	 A	 B
 Left	 Left	 C	 D
 Right	 Right	 Mandis SHOP	 www.mandis.tv



