



































Originale	Sostituto
 Power	 Power
 Timer	 Sleep
 Timer	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 <	 Left
 >	 Right
 Red	 Red
 Green	 Green

Originale	Sostituto
 Yellow	 Yellow
 Blue	 Blue
 Menu	 Menu
 Info	 Info
 Up	 Up
 Left	 I<<
 OK	 Ok
 Right	 >>I
 Down	 Down
 Guide	 Guide
 PVR	 Smart
 Plugin	 3D
 Exit	 Exit
 PIP	 Format
 Vol+	 Vol +
 Vol-	 Vol -
 Audio	 Dual





	Originale		Sostituto
	Mute		Mute
	CH+		Ch +
	CH-		Ch -
	REW		<<
	Play / Pause		Play
	Play / Pause		Pause
	FF		>>
	Rec		Rec
	File List		List
	Stop		Stop
	Radio / TV		TV/R
	FAV		Pre Ch
	Subt		Subt
	Text		Text
	www		Media
	Setup		Options
	LAN		Eject

	Originale		Sostituto
	Help		D. Menu

