


































































































Originale	Sostituto
 Power	 Power
 DVD	 Blue
 Tuner	 Green
 USB	 Yellow
 AUX	 Red
 Open/Close	 Eject
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Originale	Sostituto
 Remain	 Smart
 Cancel	 Media
 I<<	 I<<
 >>I	 >>I
 <<	 <<
 >>	 >>
 Stop	 Stop
 Play	 Play
 Pause	 Pause
 Step	 Options
 Repeat	 Text
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Tuning Up	 Ch +
 Tuning Down	 Ch -
 Menu	 Menu





Originale	Sostituto
 Return	 Back
 Up / Preset Up	 Up
 Down / Preset	 Down
 Right / Seek Up	 Right
 Left / Seek Down	 Left
 Enter	 Ok
 Audio	 List
 Subtitle	 Subt
 Info	 Info
 Exit	 Exit
 Virtual Sound	 Dual
 EQ	 3D
 Zoom/Mo/ST	 Shift + Eject
 Angle/Autoscan	 Guide

Originale	Sostituto

