



Originale	Sostituto
	Power
	Mute
	P.Mode
	S.Mode
	FAV
	Sleep
	1
	2
	3
	4
	5
	6
	7
	8
	9
	-/--
	0

Originale	Sostituto
	Back
	Vol+
	CH List
	CH+
	Vol-
	Aspect
	CH-
	EPG
	Audio
	Rec
	Menu
	Up
	Exit
	Left
	Enter
	Right
	Source





Originale	Sostituto
	Down
	Display / Media
	Red / Netflix / Search
	<< / Tune-
	Green / APP / Repeat
	>> / Tune+
	Yellow / YouTube / Repeat
	I<< / Preset-
	Blue / Prime Video / Random
	>>I / Preset+
	Text / Goto
	Stop / Hold
	Play / Slow
	Pause / Step / Freeze
	Info / Angle
	Zoom / Size
	D.Menu / Top

Originale	Sostituto
	Shift + Stop /
	Eject / Surround
	Subtitle / EQ

