

















































Originale	Sostituto
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Info	 Info / Angle
 0	 0
 Source	 AV / Input / RDS
 Home	 D.Menu / Top
 Up	 Up
 Menu	 Menu / Home

Originale	Sostituto
 Left	 Left
 OK	 OK
 Right	 Right
 Back	 Back / Return
 Down	 Down
 Exit	 Exit / Cancel / Clear
 Netflix	 Shift + Red / Netflix /
 Prime Video	 Shift + Blue / Prime
 YouTube	 Shift + Yellow / YouTube /
 Google Play	 Shift + Green / APP /
 Vol+	 Vol+
 Text / CC	 Text / Goto
 P+	 CH+ / Page+
 Vol-	 Vol-
 Smart / List	 Smart / List
 P-	 CH- / Page-
 Guide	 Guide / EPG / -/-



