











































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		6		6
	Tv/TXT		Text		7		7
	Input		AV		8		8
	OK		Ok		9		9
	Up		Up		0		0
	Down		Down		Back		Back
	Right		Right		FAV		Shift + Pre Ch
	Left		Left		Menu		Menu
	Vol+		Vol +		Exit		Exit
	Vol-		Vol -		Nicam/A2		Shift + Guide
	CH+		Ch +		Display		Shift + Info
	CH-		Ch -		Mute		Mute
	1		1		Picture		Format
	2		2		Sound		Dual
	3		3		Sleep		Sleep
	4		4		Subtitle		Subt
	5		5		EPG		Guide





Originale	Sostituto
 CH/List	 Pre Ch
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue/Screen	 Blue
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 Record	 Rec
 >>/Size	 >>
 <</Hold	 <<
 Cancel	 Shift + Back
 Reveal/Rep	 Eject
 I<</Subpage	 D. Menu
 >>/Index	 Info
 List	 List

Originale	Sostituto

