



























































Originale	Sostituto	Originale	Sostituto
On/Off	 Power	OK Enter	 Ok
Audio Off	 Mute	Menu Right	 Right
Slow Down	 Ch -	Return	 Back
Slow Up	 Ch +	Top Menu	 D. Menu
Auto/Track	 Media	Progr.	 Sleep
Title	 List	Prev.	 I<<
Subt.	 Subt	Next	 >>I
Pause	 Pause	Menu Down	 Down
Rep/A-B	 +  Shift + Text	Volume+	 Vol +
Stop	 Stop	Volume-	 Vol -
Repeat/1/All	 Text	1	 1
Zoom	 Eject	2	 2
DVD/TV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Info	6	 6
Menu Left	 Left	7	 7



Originale	Sostituto	
8		8
9		9
+10		Guide
3D		3D
Play		Play
Video		Options
F.Forward		>>
Np		TV/R
Remain		Smart
Audio		Shift + Dual
Record		Rec
0		0
Rewind		<<
Lang		Dual
C/CH		Pre Ch
Resume		Shift + Play
Play/Back		Exit

Originale	Sostituto	
Angle		Red
Random		Yellow
Echo+		Shift + Vol +
Echo-		Shift + Vol -
Shuffle		Blue
Digest		Green

