



















































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV/Radio	 TV/R
 ←PR	 Back
 FAV	 Pre Ch
 Menu	 Menu
 SAT	 Smart

Originale	Sostituto
 Info	 Info
 Page Up	 >>I
 Page Down	 I<<
 Up / PR+	 Up
 Up / PR+	 Ch +
 Down / PR-	 Down
 Down / PR-	 Ch -
 Right / Vol+ / W	 Right
 Left / Vol- / E	 Left
 Right / Vol+ / W	 Vol +
 Left / Vol- / E	 Vol -
 OK / List	 Ok
 OK / List	 List
 Exit	 Exit
 EPG	 Guide
 TV/AV	 AV
 Pause	 Shift + Pause





Originale		Sostituto		Originale		Sostituto	
	PAL/NTSC		Format				
	UHF		Media				
	Red / Audio		Red				
	Red / Audio		Dual				
	Green / Position		Green				
	Yellow / Subtitle		Yellow				
	Yellow / Subtitle		Subt				
	Blue / L/R		Blue				
	REW		<<				
	Play / Slow		Play				
	Stop		Stop				
	F.F		>>				
	Pause ( For PVR)		Pause				
	Rec		Rec				

