



































































Originale	Sostituto
 Power	 Power
 Last	 Pre Ch
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV/R	 TV/R
 Audio	 Dual
 Info	 Info
 Mode	 D. Menu

Originale	Sostituto
 Favor	 Options
 Menu	 Menu
 Sub-T	 Subt
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue







Originale	Sostituto	Originale	Sostituto
Power		Power	Power
Last		Pre Ch	Pre Ch
Mute		Mute	Mute
1		1	1
2		2	2
3		3	3
4		4	4
5		5	5
6		6	6
7		7	7
8		8	8
9		9	9
0		0	0
TV/R		TV/R	TV/R
Audio		Dual	Dual
Info		Info	Info
Mode		D. Menu	D. Menu

Originale	Sostituto	Originale	Sostituto
Favor		Options	Options
Menu		Menu	Menu
Sub-T		Subt	Subt
Exit		Exit	Exit
Up		Up	Up
Down		Down	Down
Right		Right	Right
Left		Left	Left
OK		Ok	Ok
CH+		Ch +	Ch +
CH-		Ch -	Ch -
Vol+		Vol +	Vol +
Vol-		Vol -	Vol -
Red		Red	Red
Green		Green	Green
Yellow		Yellow	Yellow
Blue		Blue	Blue







Originale	Sostituto	Originale	Sostituto
Power		Power	Power
Last		Pre Ch	Pre Ch
Mute		Mute	Mute
1		1	1
2		2	2
3		3	3
4		4	4
5		5	5
6		6	6
7		7	7
8		8	8
9		9	9
0		0	0
TV/R		TV/R	TV/R
Audio		Dual	Dual
Info		Info	Info
Mode		D. Menu	D. Menu

Originale	Sostituto	Originale	Sostituto
Favor		Options	Options
Menu		Menu	Menu
Sub-T		Subt	Subt
Exit		Exit	Exit
Up		Up	Up
Down		Down	Down
Right		Right	Right
Left		Left	Left
OK		Ok	Ok
CH+		Ch +	Ch +
CH-		Ch -	Ch -
Vol+		Vol +	Vol +
Vol-		Vol -	Vol -
Red		Red	Red
Green		Green	Green
Yellow		Yellow	Yellow
Blue		Blue	Blue



