






















































	Originale	Sostituto		Originale	Sostituto
	Power		Power		Text
	Mute		Mute		FAV
	TV/SAT		AV		P-
	SAT		Smart		P+
	TV		Media		Info
	Radio		TV/R		Up
	Recall		Back		Left
	1		1		OK
	2		2		OK
	3		3		Shift + Ok
	4		4		Right
	5		5		Down
	6		6		Menu
	7		7		Exit
	8		8		Red / Lang
	9		9		Red / Lang
	0		0		Green / Pause
					Green / Pause



