








































































| Originale | | Sostituto | | Originale | | Sostituto | |
|---|---------|---|-------|---|----------|---|----------------|
|  | Power |  | Power |  | Exit |  | Exit |
|  | Mute |  | Mute |  | Up |  | Up |
|  | 1 |  | 1 |  | Down |  | Down |
|  | 2 |  | 2 |  | Right |  | Right |
|  | 3 |  | 3 |  | Left |  | Left |
|  | 4 |  | 4 |  | Ok |  | Ok |
|  | 5 |  | 5 |  | Vol+ |  | Vol + |
|  | 6 |  | 6 |  | Vol- |  | Vol - |
|  | 7 |  | 7 |  | Sound |  | Shift + Dual |
|  | 8 |  | 8 |  | Pic |  | Shift + Format |
|  | 9 |  | 9 |  | Ch+ |  | Ch + |
|  | 0 |  | 0 |  | Ch- |  | Ch - |
|  | Audio |  | Dual |  | Sleep |  | Sleep |
|  | Recall |  | Back |  | Aspect |  | Format |
|  | Tv Menu |  | Menu |  | Freeze |  | Eject |
|  | Source |  | AV |  | Tv/Radio |  | TV/R |
|  | ChList |  | List |  | Text |  | Text |





| | Originale | Sostituto | |
|---|-----------|---|-----------------|
|  | Epg |  GUIDE | Guide |
|  | Fav |  PRE-CH | Pre Ch |
|  | Info |  DISPLAY INFO | Info |
|  | Red |  A | Red |
|  | Green |  B | Green |
|  | Yellow |  C | Yellow |
|  | Blue |  D | Blue |
|  | Reveal |  APP MEDIA | Media |
|  | Hold |  E-MANUAL D.MENU | D. Menu |
|  | Index |  SHIFT + DISPLAY INFO | Shift + Info |
|  | Subpage |  SHIFT + TIMER AV | Shift + AV |
|  | List |  HOME SMART | Smart |
|  | Mix |  SETTINGS OPT | Options |
|  | Subtitle |  AD SUBT | Subt |
|  | Size |  ECO 3D | 3D |
|  | << |  | << |
|  | >> |  | >> |

| | Originale | Sostituto | |
|---|-----------|---|-------|
|  | I<< |  | I<< |
|  | >>I |  | >>I |
|  | Play |  PLAY MODE | Play |
|  | Pause |  | Pause |
|  | Stop |  | Stop |
|  | Rec/Rep |  REC MODE | Rec |

