



| Originale   |              | Sostituto   |               | Originale   |               | Sostituto   |                |
|---|--------------|---|---------------|---|---------------|---|----------------|
|    | Power        |    | Power         |    | 8             |    | 8              |
|    | Open / Close |    | Eject         |    | 9             |    | 9              |
|    | TV / DTV     |    | TV/R          |    | -/--          |    | Shift + Guide  |
|    | Line         |    | AV            |    | 0             |    | 0              |
|    | DVD          |    | Media         |    | PRE           |    | Pre Ch         |
|    | TTX          |    | Text          |    | Vol +         |    | Vol +          |
|    | PIP ON / OFF |    | Shift + Power |    | Vol -         |    | Vol -          |
|    | PIP Swap     |    | Shift + Back  |    | Prog +        |    | Ch +           |
|    | PIP Source   |    | Shift + AV    |    | Prog -        |    | Ch -           |
|    | PIP Sound    |    | Shift + Dual  |    | M/S           |    | Subt           |
|   | 1            |   | 1             |   | Still         |   | Shift + Pause  |
|  | 2            |  | 2             |  | Sleep         |  | Sleep          |
|  | 3            |  | 3             |  | TV Menu       |  | Menu           |
|  | 4            |  | 4             |  | P.STD         |  | Format         |
|  | 5            |  | 5             |  | S.STD         |  | Shift + Subt   |
|  | 6            |  | 6             |  | P.Size        |  | Shift + Format |
|  | 7            |  | 7             |  | Exit / Cancel |  | Exit           |





| Originale   | Sostituto   |
|---|---|
|  Up              |  Up            |
|  Right           |  Right         |
|  Down            |  Down          |
|  Left            |  Left          |
|  Enter           |  Ok            |
|  Mute            |  Mute          |
|  Display         |  Shift + Info |
|  Stop            |  Stop          |
|  Play            |  Play          |
|  Pause           |  Pause         |
|  <<              |  <<            |
|  >>             |  >>           |
|  I<<           |  I<<         |
|  >>I           |  >>I         |
|  Red / Setup   |  Red         |
|  Green / Title |  Green       |
|  Yellow / Menu |  Yellow      |

| Originale  | Sostituto  |
|--|--|
|  Blue                       |  Blue         |
|  Index Repeat               |  Shift + Text |
|  MIX A-B                    |  Shift + TV/R |
|  L/F Audio                  |  Dual         |
|  Size Subtitle              |  3D           |
|  Reveal Goto                |  Back         |
|  Hold / Program / Menu      |  Shift + Menu |
|  Prepage / Angle / List     |  List         |
|  Next Page / Surround / Opt |  Options      |
|  Subpage / Zoom / EPG       |  Guide        |
|  Store / Clear / i          |  Shift + Exit |
|  Store / Clear / i         |  Info        |

