

















































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Exit		Exit / Cancel / Clear
	16:9		Picture / Format		Reveal / EPG		Guide / EPG / -/-
	Mute		Mute / Dimmer		Source		AV / Input / RDS
	1		1		Info		Info / Angle
	2		2		Menu		Menu / Home
	3		3		Red		Red / Netflix / Search
	4		4		Up		Up
	5		5		Yellow		Yellow / YouTube / Repeat
	6		6		Left		Left
	7		7		OK		OK
	8		8		Right		Right
	9		9		Green		Green / APP / Repeat
	0		0		Down		Down
	Back		Back / Return		Blue		Blue / Prime Video / Random
	Repeat		Shift + Green / APP /		Vol+		Vol+
	List Fav		Smart / List		P+		CH+ / Page+
	List Fav		Fav / Marker / PC		Vol-		Vol-





Originale		Sostituto		Originale	Sostituto
P v	P-		CH- / Page-		
TTX	TTX		Text / Goto		
REC	Rec		Rec / Rec Mode		
T-Shift	T-Shift		Sleep / Timer		
AD	AD	 + 	Shift + Audio / Lang I/II		
	Index / Play/Pause		Play / Slow		
	Zoom / Stop		Zoom / Size		
	Zoom / Stop		Stop / Hold		
	Hold / I<<	 + 	Shift + Stop /		
	Hold / I<<		I<< / Preset-		
	Language / >>I		Sound / Title		
	Language / >>I		>>I / Preset+		
	Subtitle		Subtitle / EQ		
	Audio		Audio / Lang I/II		

