

































































Originale	Sostituto
 Standby	 Power
 AV	 AV
 Mute	 Mute
 16:9 / Angle	 Format
 Zoom	 Shift + Eject
 Subt	 Subt
 Audio	 Dual
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Originale	Sostituto
 Back	 Back
 Exit / Clear	 Exit
 FAV / Program	 Shift + Pre Ch
 EPG / Goto	 Guide
 Info / Display	 Info
 Menu	 Menu
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Vol -	 Vol -
 Vol +	 Vol +
 PR -	 Ch -
 PR +	 Ch +
 Red / Title	 Red
 Green / Root	 Green





Originale		Sostituto		Originale		Sostituto	
	Yellow / Repeat		Yellow				
	Blue / A-B		Blue				
	TXT / I<<		Text				
	TXT / I<<		I<<				
	Sound / >>I	 + 	Shift + Dual				
	Sound / >>I		>>I				
	Picture / <<	 + 	Shift + Format				
	Picture / <<		<<				
	Swap / >>		Pre Ch				
	Swap / >>		>>				
	Eject		Eject				
	Play / Pause		Play				
	Play / Pause		Pause				
	Stop		Stop				
	Setup		D. Menu				

