







































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Angle	 Info / Angle
 Goto	 Text / Goto	 Audio	 Audio / Lang I/II
 Source	 AV / Input / RDS	 PBC	 Fav / Marker / PC
 Mute	 Mute / Dimmer	 Title	 Sound / Title
 1	 1	 Up	 Up
 2	 2	 Stop	 Stop / Hold
 3	 3	 Play	 Play / Slow
 4	 4	 Pause	 Pause / Step / Freeze
 5	 5	 Left	 Left
 6	 6	 Enter	 OK
 7	 7	 Right	 Right
 8	 8	 Slow	 Shift + Play /
 9	 9	 Setup	 Setup / OPT /
 0	 0	 Down	 Down
 10+	 Guide / EPG / -/--	 Zoom	 Zoom / Size
 Step	 Shift + Pause / Step /	 Menu	 Menu / Home
 Subtitle	 Subtitle / EQ	 Repeat	 Green / APP / Repeat

Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Angle	 Info / Angle
 Goto	 Text / Goto	 Audio	 Audio / Lang I/II
 Source	 AV / Input / RDS	 PBC	 Fav / Marker / PC
 Mute	 Mute / Dimmer	 Title	 Sound / Title
 1	 1	 Up	 Up
 2	 2	 Stop	 Stop / Hold
 3	 3	 Play	 Play / Slow
 4	 4	 Pause	 Pause / Step / Freeze
 5	 5	 Left	 Left
 6	 6	 Enter	 OK
 7	 7	 Right	 Right
 8	 8	 Slow	 Shift + Play /
 9	 9	 Setup	 Setup / OPT /
 0	 0	 Down	 Down
10+	Guide / EPG / -/--	Zoom	 Zoom / Size
Step	Shift + Pause / Step /	Menu	 Menu / Home
Subtitle	Subtitle / EQ	Repeat	 Green / APP / Repeat





Originale	Sostituto	Originale	Sostituto
AB	A-B		
⏮	I<<		
⏭	>>I		
PROGRAM	Program		
DISPLAY	Display		
⏪	<<		
⏩	>>		

