












Originale	Sostituto	Originale	Sostituto
	Power		Power
	SAT		AV
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Texts		Smart
	Back		Back
	Vol +		Vol +
	Vol -		Vol -

Originale	Sostituto	Originale	Sostituto
	Menu		Menu
	Exit		Exit
	Guide		Guide
	CH +		Ch +
	CH -		Ch -
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Page Down		Shift + Ch -
	Page Up		Shift + Ch +
	Info		Info
	Subtitle		Subt
	Audio		Dual
	Check		Shift + Ok
	Red		Red





Originale	Sostituto	Originale	Sostituto
 Green	 Green	 <<	 <<
 Yellow	 Yellow	 >>	 >>
 Blue	 Blue	 List	 List
 Res	 Format	 Zoom	 Eject
 Sleep	 Sleep	 Mark	 Pre Ch
 TV / Radio	 TV/R		
 Text	 Text		
 Play	 Play		
 Stop	 Stop		
 Pause	 Pause		
 Rec	 Rec		
 Repeat	 Shift + Text		
 Step	 Shift + Pause		
 <<	 <<		
 >>	 >>		
 Picture	 Shift + Format		
 Play Text	 Shift + Play		

Originale	Sostituto
 <<	 <<
 >>	 >>
 List	 List
 Zoom	 Eject
 Mark	 Pre Ch

