









Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Up	 Up
 Info	 Info / Angle	 Left	 Left
 Mute	 Mute / Dimmer	 Enter	 OK
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 CH+	 CH+ / Page+
 4	 4	 Index	 Display / Media
 5	 5	 Vol+	 Vol+
 6	 6	 CH-	 CH- / Page-
 7	 7	 List	 Smart / List
 8	 8	 Vol-	 Vol-
 9	 9	 Fav / Marker / PC	 Fav / Marker / PC
 Source	 AV / Input / RDS	 Sleep	 Sleep / Timer
 0	 0	 EPG	 Guide / EPG / -/-
 O)/I-II/Audio	 Audio / Lang I/II	 Recall	 Back / Return
 Menu	 Menu / Home	 Red	 Red / Netflix / Search
 Exit	 Exit / Cancel / Clear	 <<	 << / Tune-

Originale	Sostituto	Originale	Sostituto
 Up	 Up	 Left	 Left
 Left	 Left	 Enter	 OK
 Right	 Right	 Down	 Down
 Down	 Down	 CH+	 CH+ / Page+
 CH+	 CH+ / Page+	 Index	 Display / Media
 Index	 Display / Media	 Vol+	 Vol+
 Vol+	 Vol+	 CH-	 CH- / Page-
 CH-	 CH- / Page-	 List	 Smart / List
 List	 Smart / List	 Vol-	 Vol-
 Vol-	 Vol-	 Fav / Marker / PC	 Fav / Marker / PC
 Fav / Marker / PC	 Fav / Marker / PC	 Sleep	 Sleep / Timer
 Sleep	 Sleep / Timer	 EPG	 Guide / EPG / -/-
 EPG	 Guide / EPG / -/-	 Recall	 Back / Return
 Recall	 Back / Return	 Red	 Red / Netflix / Search
 Red	 Red / Netflix / Search	 <<	 << / Tune-
 <<	 << / Tune-		







































Originale		Sostituto		Originale	Sostituto
	Green		Green / APP / Repeat		
	>>		>> / Tune+		
	Yellow		Yellow / YouTube / Repeat		
	I<<		I<< / Preset-		
	Blue		Blue / Prime Video / Random		
	>>I		>>I / Preset+		
	[=]		Text / Goto		
	Play		Play / Slow		
	Pause		Pause / Step / Freeze		
	[=+]		Zoom / Size		
	Stop/Still		Stop / Hold		
	Radio		TV/Radio /		
	[=◇]/[++]		Setup / OPT /		
	[=x]		Picture / Format		
	[=o]/Subtitle		Subtitle / EQ		
	DMP		D.Menu / Top		
	Rec		Rec / Rec Mode		





































Originale	Sostituto
 Power	 Power
 Mute	 Mute / Dimmer
 Text / Play/Pause	 Play / Slow
 Text / Play/Pause	 Pause / Step / Freeze
 Stop / Still	 Stop / Hold
 Rec	 Rec / Rec Mode
 Audio I/II	 Audio / Lang I/II
 Subtitle / [≡o]	 Subtitle / EQ
 [≡x]	 Picture / Format
 Size / Aspect	 Zoom / Size
 Sleep	 Sleep / Timer
 Radio	 TV/Radio /
 DMP	 D.Menu / Top
 Source	 AV / Input / RDS
 Menu	 Menu / Home
 Up	 Up
 Info	 Info / Angle

Originale	Sostituto
 Left	 Left
 Enter	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Recall	 Back / Return
 Vol +	 Vol+
 List	 Smart / List
 CH +	 CH+ / Page+
 Vol -	 Vol-
 Index	 Display / Media
 CH -	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5





Originale		Sostituto		Originale	Sostituto
	6		6		
	7		7		
	8		8		
	9		9		
	EPG		Guide / EPG / -/-		
	0		0		
	Fav		Fav / Marker / PC		
	Red / <<		Red / Netflix / Search		
	Green / >>		Green / APP / Repeat		
	Yellow / <<		Yellow / YouTube / Repeat		
	Blue / >>		Blue / Prime Video / Random		
	Text / Play/Pause		Shift + Play /		
	Red / <<		Shift + Red / Netflix /		
	Green / >>		Shift + Green / APP /		
	Yellow / <<		Shift + Yellow / YouTube /		
	Blue / >>		Shift + Blue / Prime		

