




Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Yellow/Zoom	 Yellow
 Mute	 Mute	 Blue/Option	 Blue
 Rec	 Rec	 Info	 Info
 Goto	 Smart	 FAV	 Pre Ch
 Aspect	 3D	 Menu	 Menu
 V.Format	 Format	 Exit	 Exit
 <<	 <<	 Up/CH+	 Up
 >>	 >>	 Down/CH-	 Down
 Play	 Play	 Right/Vol+	 Right
 Pause	 Pause	 Left/Vol-	 Left
 Stop	 Stop	 OK	 Ok
 Tv/Radio	 TV/R	 Vol+	 Vol +
 Audio	 Dual	 Vol-	 Vol -
 Dev	 Options	 SAT	 Media
 Recall	 Back	 EPG	 Guide
 Red/TTX	 Red	 Page+	 Ch +
 Green/SUB.T	 Green	 Page-	 Ch -

Originale	Sostituto	Originale	Sostituto
 TV	 DVD	 SAT	 AUX
 PLAY MODE	 REC MODE	 Play	 Pause
 <<<	 >>>	 Stop	 Play
 LIST	 SOUND	 AD	 SETTINGS
 PROG	 SEARCH	 PICTURE	 ECO
 SLEEP	 TV/R	 FORMAT	 3D
 E-MANUAL	 REPEAT	 ZOOM	 TIMER
 D.MENU	 TEXT	 Up	 AV
 TOP MENU	 DISPLAY INFO	 MENU	 INFO
 CLEAR EXIT	 EXIT	 OK	 BACK
 EXIT	 HOME SMART	 Vol+	 CH +
 Vol+	 APP MEDIA	 Vol-	 CH -
 Vol-	 MEDIA	 SAT	 FAV
 SAT	 GUIDE	 EPG	 PRE-CH
 EPG	 GUIDE	 Page+	 Ch +
 Page+	 Ch +	Page-	Ch -
Page-	Ch -		





Originale		Sostituto	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FIND	Find	TIMER AV	AV
MP	MP	DISC NAV LIST	List

Originale		Sostituto	

