





































Originale	Sostituto
 Power	 Power
 Energy Saving	 3D
 AV Mode	 Shift + AV
 Input	 AV
 TV / Rad	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List
 Q.View	 Pre Ch

Originale	Sostituto
 Vol +	 Vol +
 Vol -	 Vol -
 Fav Mark	 Shift + Pre Ch
 Ratio	 Format
 Mute	 Mute
 P + / Page +	 Ch +
 P - / Page -	 Ch -
 Menu	 Menu
 Guide	 Guide
 Q.Menu	 D. Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Back	 Back
 Info	 Info



