



















































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 9	 9
 <<	 <<	 0	 0
 >>	 >>	 i	 Info
 Stop	 Stop	 Rec	 Rec
 Play/Pause	 Play	 Vol+	 Vol +
 Red	 Red	 Vol-	 Vol -
 Green	 Green	 CH+	 Ch +
 Yellow	 Yellow	 CH-	 Ch -
 Blue	 Blue	 Guide	 Guide
 1	 1	 Mute	 Mute
 2	 2	 FAV	 Pre Ch
 3	 3	 Text	 Text
 4	 4	 Menu	 Menu
 5	 5	 Exit	 Exit
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right





Originale	Sostituto
 Left	 Left
 OK	 Ok
 Back	 Back
 Lang(AD)	 Dual
 Subtitle	 Subt
 Tv/Radio	 TV/R

Originale	Sostituto

