

















Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Guide	 Guide
 1	 1	 ?	 Info
 2	 2	 Back	 Back
 3	 3	 Exit	 Exit
 4	 4	 Tools	 Options
 5	 5	 OK	 Ok
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 Mute	 Mute
 FAV	 Pre Ch	 Vol+	 Vol +
 TXT	 Text	 Vol-	 Vol -
 Red	 Red	 P+	 Ch +
 Green	 Green	 P-	 Ch -
 Yellow	 Yellow	 I<	 I<<
 Blue	 Blue	 >I	 >>I





Originale		Sostituto	
	<<		<<
	>>		>>
	Rec		Rec
	Play		Play
	Pause		Pause
	Stop		Stop
	3D		3D
	[...]..		Subt
	Menu		Menu
	..OQ		Format
	@		Smart
	My Media		Media
	Netflix		D. Menu
	Source		AV

Originale		Sostituto	

