











Originale	Sostituto
 Power	 Power
 Text	 Text
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Tv/J	 TV/R
 Menu	 Menu
 APP	 Media
 Disp	 Shift + Info
 Back	 Back
 Exit	 Exit
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down

Originale	Sostituto
 EPG	 Guide
 Info	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 Play	 Play
 Pause	 Pause
 Mute	 Mute
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8





	Originale	Sostituto		Originale	Sostituto
	9		9		
	0		0		
	List		List		
	Opt.		Options		

