






Originale	Sostituto	Originale	Sostituto
 Standby	 Power	 Pause	 Pause / Step / Freeze
 1	 1	 Vol -	 Vol-
 2	 2	 Up	 Up
 3	 3	 Left	 Left
 4	 4	 OK	 OK
 5	 5	 Right	 Right
 6	 6	 Down	 Down
 7	 7	 Exit	 Exit / Cancel / Clear
 8	 8	 Menu	 Menu / Home
 9	 9	 Red / SUB-T	 Subtitle / EQ
 TV / STB	 AV / Input / RDS	 Red / SUB-T	 Red / Netflix / Search
 0	 0	 Green	 Green / APP / Repeat
 TV / Radio	 TV/Radio /	 Yellow / Timer	 Yellow / YouTube / Repeat
 CH +	 CH + / Page+	 Blue / Info	 Blue / Prime Video / Random
 Mute	 Mute / Dimmer	 Blue / Info	 Info / Angle
 Vol +	 Vol+	 P.STD	 Picture / Format
 CH -	 CH - / Page-	 P.Size	 Zoom / Size

Originale	Sostituto	Originale	Sostituto
 Standby	 Power	 Pause	 Pause / Step / Freeze
 1	 1	 Vol -	 Vol-
 2	 2	 Up	 Up
 3	 3	 Left	 Left
 4	 4	 OK	 OK
 5	 5	 Right	 Right
 6	 6	 Down	 Down
 7	 7	 Exit	 Exit / Cancel / Clear
 8	 8	 Menu	 Menu / Home
 9	 9	 Red / SUB-T	 Subtitle / EQ
 TV / STB	 AV / Input / RDS	 Red / SUB-T	 Red / Netflix / Search
 0	 0	 Green	 Green / APP / Repeat
 TV / Radio	 TV/Radio /	 Yellow / Timer	 Yellow / YouTube / Repeat
 CH +	 CH + / Page+	 Blue / Info	 Blue / Prime Video / Random
 Mute	 Mute / Dimmer	 Blue / Info	 Info / Angle
 Vol +	 Vol+	 P.STD	 Picture / Format
 CH -	 CH - / Page-	 P.Size	 Zoom / Size



