

























	Originale	Sostituto	Originale	Sostituto
	Power	 Power		
	((·))	 Smart		
	+	 Vol +		
	-	 Vol -		
	>>			
	<<			
	Play	 Play		
	Pause			
	Up			
	Down			
	Menu	 Menu		
	Select	 Ok		
	X	 Exit		
	Recall	 Back		

